


de Raumtemperaturfühler, Unterputz
 fr Sonde de température ambiante, encastrée
 en Room temperature sensor, recessed
 it Sensore di temperatura ambiente, installazione a incasso
 es Sonda de temperatura para sala, instalación bajo revoque
 sv Omgivningstemperatürgivare, infälld montering
 nl Ruimtetemperaturopnemer, inbouw

de Montagevorschrift
 fr Instruction de montage
 en Fitting instructions
 it Istruzioni di montaggio
 es Instrucciones de montaje
 sv Monteringanvisning
 nl Montagevoorschrift

EGT 386, 388


EGT 486

EGT 686, 688



de Installationsanweisung für die Elektrofachkraft
 fr Notice d'installation pour l'électricien
 en Guidelines for the electrician
 it Informazioni per l'installatore elettrico
 es Instrucciones de instalación para el electricista
 sv Installationsinstruktion för behörig elektriker
 nl Installatie aanwijzing voor de elektromonteur


de Für den Einsatz in üblicher Umgebung
 fr Pour usage dans un environnement normal
 en For use in normal environments
 it Per impiego in ambiente usuale
 es Para el uso en ambiente normal
 sv För användning i normal miljö
 nl Voor toepassing in normale omgeving




IP20
EN60529




i EGT 386, 486, 686




i EGT 388, 688



1a EGT 386, 486, 686





1b EGT 388, 688




1b


EGT 388, 688

**2**

de abdichten
fr rendre étanche
en seal
it otturare
es junta
sv avtätning
nl afdichten

3aEGT 386
EGT 486
EGT 686**3b**


EGT388F101



1	2	3	4	5	6	7	8	9	10
		GND	XS	MAX. 10V					

3c


EGT388F102



1	2	3	4	5	6	7	8	9	10
		GND	XS	MAX. 10V					

3d

EGT688F101



1	2	3	4	5	6	7	8	9	10
		GND	XS	MAX. 10V					

de Dokument aufbewahren
fr Ce document est à conserver
en Retain this document
it Conservare il documento
es Guardar el documento
sv Spara dokumentationen
nl Document bewaren

© SAUTER Head Office
Fr. Sauter AG
Im Surinam 55
CH-4016 Basel
Tel. +41 61 - 695 55 55
Fax +41 61 - 695 55 10
www.sauter-controls.com
info@sauter-controls.com